

# AK SAW Style Pistol Grip

1. **Make sure your rifle is unloaded and ensure that there is no ammunition in the chamber.**
2. **Remove the recoil spring, bolt carrier assembly, and current pistol grip.**



3. **Insert the provided bolt and lock washer into the pistol grip. While holding the original pistol grip lug inside the receiver, tighten the bolt with a 10mm socket. The orientation of the lug should slant rearward.**



4. **Reassemble the rifle and preform a function check to ensure everything is in working order.**

