



AK Wire Retaining Spring

1. **Make sure your rifle is unloaded and ensure that there is no ammunition in the chamber.**
2. The retaining spring should go around the trigger pin and under the hammer pin. The picture of the stripped receiver should give you an idea of how the device is installed.

