



THIS PRODUCT IS BACKED BY A LIFETIME GUARANTEE.
FOR PRODUCT SUPPORT AND UPDATES PLEASE
REGISTER YOUR PRODUCT AT
[TAPCO.COM/REGISTRATION](https://tapco.com/registration)

TAPCO AK RETAINING PLATE

AK0690

BEGIN BY MAKING SURE YOUR RIFLE IS UNLOADED

1. REMOVE YOUR RECEIVER COVER, RECOIL SPRING, BOLT, BOLT CARRIER, SAFETY LEVER AND ORIGINAL RETAINING SPRING/PLATE.
2. THE TAPCO RETAINING PLATE WILL INSTALL WITH THE "TAPCO USA" RIGHTSIDE UP AND FACING THE INSIDE OF THE RECEIVER.
3. ANGLE THE OPEN SIDE DOWNWARD AROUND THE GROOVE IN THE HAMMER PIN AGAINST THE RECEIVER. (BE CAREFUL TO ENSURE NOTHING IS BETWEEN THE RETAINING PLATE AND THE RECEIVER)
4. SLIDE THE RETAINING PLATE DOWN ONTO THE TRIGGER PIN AND LINE UP THE PROPER HOLE IN THE TOP LEFT CORNER OF THE PLATE WITH THE SAFETY PIN HOLE. (DIFFERENT AK VARIANTS WILL UTILIZE DIFFERENT HOLES; USE THE HOLE THAT MAINTAINS A HOLD OF THE HAMMER AND TRIGGER PINS)
5. INSTALL THE SAFETY LEVER MAKING SURE THAT THE LEVER SECURES THE PLATE IN PLACE, UTILIZING THE HOLE IN THE RETAINING PLATE. ENSURE THAT THE RETAINING PLATE IS FLUSH AGAINST THE RECEIVER WALL.
6. REASSEMBLE YOUR RIFLE AND PERFORM A SAFETY CHECK BEFORE FIRING.

